

UPDATING THE FIRMWARE

The version of your GL800's firmware can be updated by rewriting the flash ROM on the pertinent circuit boards. You can upgrade the firmware by loading the update program to a USB memory device.

1. How to Updating the GL800 Flash ROM from the USB memory device


Preparations for the update

Firmware :Mxxxa001.G80← Main Program file for GL800

:Mxxxa002.G80← Main Program file for GL800


- (1) Connect the AC adapter for the GL800.
- (2) Turn on the GL800.
- (3) Copy the two main program files to a USB memory device from the computer.

(Copy the two main program files to root directory of a USB memory. Do not copy them to any folder.)



How to upgrade

- (1) Insert the USB memory device containing the main upgrade program into the GL800's USB port.



- (2) Turn on the GL800 to automatically execute the upgrade program.
- (3) Wait until the display shown below appears or until the beeper sound stops.

Note:

Don't turn off the GL800 until this process is finished.

GL800

The following message will appear on the GL800 display in yellow characters when the upgrade is complete. Also the beeper will sound for 5 seconds.

"Please Turn Off the Power. I have locked up."



- (4) Turn off the power to the GL800 when the above message is displayed or when the beeper sound stops.
- (5) Delete the two main program files from a USB memory device.
This is to avoid upgrading the firmware by mistake.