

UPDATEING THE FIRMWARE

The version of your GL200/GL200A's firmware can be updated by rewriting the flash ROM on the pertinent circuit boards. You can update the firmware by loading the update program to a USB memory device.

How to Update the GL200/A Flash ROM from the USB memory device

Preparations for the update

Firmware :Mxxxa001.G20← Main Program file for GL200/GL200A
:Mxxxa002.G20← Main Program file for GL200/GL200A

Note:

The former firmware version of 2.00 are for the GL200.

The firmware version from 2.00 is for the GL200A.

- (1) Connect the AC adapter for the GL200/GL200A.
- (2) Turn on the GL200/GL200A.
- (3) Copy the two main program files to a USB memory device from the computer.

How to update

- (1) Insert the USB memory device containing the main update program into the GL200/GL200A's USB port.
- (2) Turn on the GL200/GL200A to automatically execute the update program.
- (3) Wait until the display shown below appears or until the beeper sound stops.


Note:

Don't turn off the GL200/GL200A until this process is finished.

GL200/GL200A

The following message will appear on the GL200/GL200A display in yellow characters when the upgrade is complete. Also the beeper will sound for 5 seconds.

"Please Turn Off the Power. I have locked up."



- (4) Turn off the power to the GL200/GL200A when the above message is displayed or when the beeper sound stops.
- (5) Delete the two main program files from the USB memory device.
This is to avoid upgrading the firmware by mistake.